Water greases molecular machines

Molecular machines have been designed that can fulfill roles such as molecular switches, motors, and brakes. The mechanical behavior of these constructs differs from their macroscopic counterparts. For example, the concept of a conventional liquid lubricant makes no sense at the molecular scale. Despite this, water appears to have an accelerating effect on the movement of molecular machines based on hydrogen-bonded components, as described in the September 1 online edition of *Nature Chemistry* (DOI: 10.1038/NCHEM.1744).

M.R. Panman of the University of Amsterdam, E.R. Kay of the University of Edinburgh, D.A. Leigh of Edinburgh and the University of Manchester, and their colleagues studied a rotaxane "molecular shuttle" in which a peptidebased macrocycle can bind to either of two hydrogen accepting "stations." In the neutral state, the succinamide site is the more stable position, but a short pulse of UV light excites the napthalimide group to a radical anion and induces the macrocycle to switch places.

The research team found that an addition of just 3% deuterated water to the system brought about a twofold increase in the rate of movement, while other hydrogen bonding solvents such as methanol, ethanol, and butanol had an insignificant or negative effect. A similar effect was also found for the thermal rotation of the macrocycle around the succinamide site, where the rotation rate could be doubled by adding 5% deuterated water.

Possible straightforward explanations for this phenomenon such as changes in viscosity and solvent polarity could be ruled out as the solvent properties do not correlate with the observed trends. Instead, the researchers propose that the ability of water to form a three-dimensional hydrogen-bonded structure is key, as this can stabilize the detached state of the macrocycle and increase the probability of it leaving a binding site. The small size of the molecule also allows the structure to quickly rearrange as the parts reposition. Evidence for this is provided by observation of hydrogen bonding between the water and the macrocycle peptide linkages in infrared spectroscopy.

This research provides useful insight into the translation of biological motors, where it has already been speculated that water plays an important role in "lubricating" protein folding and molecular



The structure and operation cycle of the molecular shuttle in acetonitrile. In the uncharged state, the macrocycle (blue) binds to the succinamide (green) site, but laser excitation of the napthalimide (red) site to a radical anion renders it a better hydrogen bond acceptor and induces the macrocycle to change places. Reproduced with permission from *Nature Chem.* **8** (2013), DOI: 10.1038/NCHEM.1744. © 2013 Macmillan Publishers Ltd.

rotors. While it is not possible to study biological systems in solvents other than water, synthetic machines such as these are able to put the principle to the test in a range of different solvents.

**Toby Lockwood** 

#### Energy Focus

Perovskite-based planar heterojunction solar cell achieves record efficiency

Researchers looking for ways to voltaics have recently begun studying perovskites. These are inexpensive materials with the same crystal structure as calcium titanium oxide, from which they draw their name. To date, researchers have demonstrated a series of photovoltaic cells that incorporate perovskites in relatively complex device architectures that generally require complex processing steps and high temperatures. Now, Mingzhen Liu and colleagues at the University of Oxford have demonstrated a simple planar perovskite-based solar cell that avoids these issues and achieves over 15% efficiency. They reported their results in the September 19 issue of *Nature* (DOI: 10.1038/nature12509; p. 395).

The active layer in photovoltaic cells has three essential functions: absorption of light, generation of free carriers, and transport of those carriers to their respective contacts. Researchers have recently investigated the potential of organometallic trihalide perovskites to play one or more of these roles in nanostructured solar cells, although in all of these cases, other materials were also present to serve as a structured scaffold. The Oxford researchers hypothesized that it might be possible to build a high-efficiency device using perovskites with a simple planar heterojunction architecture, eliminating the scaffolding and using the perovskite material to serve all three essential functions of the active layer. This would put the device in the same structural category as industrially relevant silicon and thin-film solar cells, and therefore be an important step forward.

To test this hypothesis, the researchers fabricated devices based on a fluorine-doped tin oxide (FTO)-coated glass (the device anode), followed by a spincoated layer of compact  $TiO_2$  as an electron-sensitive contact. Next, they deposited a layer of the mixed halide perovskite  $CH_3NH_3PbI_{3-x}Cl_x$  using two different methods: two-phase vapor deposition, and spin-coating. Both

# ATOMIC RESOLUTION S/TEM

## Unrivaled raw data you can believe.

Atom-by-atom sub-angstrom imaging resolution, atom-to-atom chemical mapping, aberration correction, 2 and 3-D reconstruction, and optional Cold FEG. What can we help you achieve?

#### **Dr. John Bradley** University of Hawaii *Commercial NCM Catho*

*Commercial NCM Cathode Material for Li-Ion Batteries. Atomic EDS map. Overlay shows O (red), Ni (blue), Mn (green).* 

0.5nm

10

#### Dr. Miguel Jose Yacaman University of Texas, San Antonio

Sample provided by Tour Lab, Rice University Chiral Nanotube with parameters n=10 and m=4 (simulated and experimental).

o.5nm

#### **Dr. Moon Kim** University of Texas, Dallas STEM HAADF image of transferred MoS<sub>2</sub>, showing Mo and S atom positions and their 2H stacking sequence.

o.5nm



www.jeolusa.com salesinfo@jeol.com 978-535-5900

MRS Booth 300

IEM-ARM200F

#### Solutions for Innovation



9

# **SPECIAL OFFER for MRS Bulletin Subscribers**

### **Essential References in Materials Science**



## Attending MRS Fall Meeting? Visit CRC Press Booth #107.

CRC Press

SAVE 25% when you order online and use promo code KJM47.

www.CRCPRESS.com

e-mail: orders@crcpress.com • 1-800-634-7064 • 1-859-727-5000 • +44 (0) 1235 400 524

SAVE

approaches used methylammonium iodide and lead chloride as the organic and inorganic precursor salts, respectively. Finally, the researchers spin-coated a *p*type hole conductor—2,2',7,7'-tetrakis-(N,N-di-*p*-methoxyphenylamine)9,9'spirobifluorene(spiro-OMeTAD)—on the perovskite layer, followed by a silver cathode to complete the device.

Using x-ray diffraction, the researchers found good phase purity in the perovskite layer for both vapor-deposited and spin-coated devices. However, the morphologies were quite different; the vapor-deposited film had a uniform thickness of 330 nm, while the spincoated film was highly structured, varying between 0 nm and 465 nm. When tested under simulated sunlight, the most efficient vapor-deposited device displayed 15.4% efficiency, while the best solution-processed device showed a 8.6% efficiency. An ensemble of 12 vapor-deposited devices displayed an average efficiency of 12.3%, demonstrating some variability.

These results are highly encouraging for the potential use of perovskite materials in solar cells, particularly because these devices achieve high efficiencies with a simple planar heterojunction architecture and because vapor deposition is compatible with existing silicon and thin-film solar-cell processing infrastructure. The researchers also said that vapor-deposited perovskites might be able to play an important role as a "top cell" in multijunction silicon or copper indium gallium diselenide devices, improving their overall efficiencies. It is clear that perovskites are worth watching for high-efficiency, low-cost solar power.

**Colin McCormick** 

MRS Booth 404



www.mrs.org/join

MRS MATERIALS RESEARCH SOCIETY

# **High Resolution RBS**

National Electrostatics Corporation has added Ångstrom level, High Resolution RBS to the RC43 Analysis System for nanotechnology applications. A single Pelletron instrument can now provide RBS, channeling RBS, microRBS, PIXE, ERDA, NRA, and HR-RBS capability, collecting up to four spectra simultaneously. Pelletron accelerators are available with ion beam energies from below 1 MeV in to the 100 MeV region.

www.pelletron.com Phone: 608-831-7600 E-mail: nec@pelletron.com Full wafer version of the model RC43 analysis end station with High Resolution RBS Detector.

National Electrostatics Corp